



## INSTRUCTIONS:

1. REMOVE ORIGINAL string trimmer head (see original equipment manufacturer's owner's manual for proper removal procedure.)
2. Carefully mount the "TAS TRIMMER" unit flush against the bottom of the string trimmer's driving disk. Make sure blade side of "TAS TRIMMER" is facing away from shaft bottom.
3. Turn the blade shaft until one of the driving disk holes lines up with the respective gear housing hole. INSERT a locking pin into the hole to lock the shaft.
4. Attach the mounting nut or bolt (depending on type of string trimmer being used) on the underside of the "TAS TRIMMER" and secure it tightly with a wrench.
5. To remove: simply reverse the procedure.
6. Fill the angle gear with grease before using.

**WARRANTY:** Limited 30-day warranty on defective parts and materials. Substitution of any parts other than manufacturer's approved original or replacement parts voids and otherwise nullifies warranty claims.

**RECOMMENDED USAGE:** 24.0 - 30.0 cc gasoline powered string trimmers. Not to be used with electrically powered machines.

**REPLACEMENT:** Manufacturer recommends replacement when 50% or more of the blades are worn down.

---

***THE "TAS TRIMMER" FITS ANY STRAIGHT SHAFT LINE TRIMMER, THAT IS BRUSH CUTTER ADAPTABLE.  
OPERATION OF THE "TAS TRIMMER" SHOULD NOT EXCEED 1/2 THROTTLE SPEED.***

---

**Caution:** Always wear eye and body protective wear when using this product. Do not operate around people or animals. Read instructions for use carefully before using tool.

Made in USA  
Copyright 1993-2022© TAS Industries Inc.  
All Rights Reserved.



P.O. Box 1686  
Venice, FL 34284-1686